

## Software update SEFRAM 7880, 7881, 7882, 7885



**Caution:** Take care that the remaining battery life is sufficient (> 30%), else plug the appliance on the mains with the provided adapter.

You can easily update the software to get new functionalities.  
The update requires an USB stick.

To achieve the update:

- Download the update file **788x.zip file** on our website ([www.sefram.fr](http://www.sefram.fr))
- Insert a USB stick on your PC
- Unzip the file onto the root of the memory stick
- Pull the USB stick off from your computer
- Turn your appliance on
- Insert the USB stick into the connector of the appliance.

- Go to Configuration page, press



After 10 seconds waiting, the update start.



**Warning:** Do not turn the appliance off while updating

The updating process lasts about 10 minutes.

At the end of the update, the appliance asks you to restart. The software is then loaded into your appliance.

Few Error messages may show up: **Do not take them into account.**